# IN-HOUSE PROCEDURE #

# PROCEDURE FOR AC GAUGE LEAK TESTS

ŀ	tom	٠.
	ш	I.

AC Gauge Leak Test

## Purpose:

This method provides instructions for conducting a leak test on a nuclear asphalt content gauge.

## Inspection Equipment Required:

1. Leak test kit

#### Tolerance:

Equipment shall meet the requirements of the U.S. Nuclear Regulatory Commission (NRC).

### Procedure:

- 1. Attach your radiation monitoring badge to your body as required.
- 2. Open the chamber door.
- 3. In the top of the chamber, there is a small round opening. Wipe the opening with the wipe disk using tongs or with a wipe swab. If the wipe disk is attached to a paper pad, do not remove the wipe disk from the pad.
- 4. Seal the wipe disk into the plastic bag, fill out all the information requested, and complete the leak test form.
- 5. Secure the gauge properly.
- 6. Mail the completed form and wipe test to the testing laboratory.

