

## Speedy Moisture Tester Calibration Worksheet

Equipment ID: _____	Date: _____
Manufacturer: _____	Performed By: _____
Model #: _____	Last Calibration: _____
Serial #: _____	Next Calibration Due: _____
Storage Location: _____	

Calibration Item: Verify moisture content results  
 Calibration Procedure: In-House Procedure for Verifying Speedy Moisture Testers  
 Calibration Equipment: Oven capable of maintaining  $230 \pm 9$  °F ( $110 \pm 5$  °C)

Oven ID: \_\_\_\_\_  
 Scale readable to 0.1 % of sample mass or better  
 Scale ID \_\_\_\_\_

Oven MC Data	Sample 1	Sample 2	Sample 3
Tare Weight			
Wet Wt. + Tare Wt.			
Dry Wt. + Tare Wt.			
Dry Wt. of Soil			

Oven Moisture Content			
Speedy Moisture Content			
Tolerance	$\pm 1.5$ %		
Pass / Fail	<input type="checkbox"/> Pass <input type="checkbox"/> Fail	<input type="checkbox"/> Pass <input type="checkbox"/> Fail	<input type="checkbox"/> Pass <input type="checkbox"/> Fail

Pass / Fail \_\_\_\_\_  
 Initial By \_\_\_\_\_